

Section 6 - Procedure for Measuring Maximum Static Back Pressure

Eminox Ltd always uses a maximum static back pressure value to decide if a CRT[®] System needs servicing. A maximum static back pressure test can be carried out using the Electronic Service Indicator unit. The unit is reset, the test carried out and the maximum value read from the unit by the operator performing the test.

Maximum static (or unloaded) back pressure readings are taken as follows:

- 1** Stop the engine
- 2** Reset the display so that it reads M000
- 3** Ensure the vehicle is in neutral and the parking brake applied
- 4** With the engine at normal operating temperature bring to maximum engine speed
- 5** Hold the full throttle position for approximately 15 seconds and release
- 6** Stop the engine
- 7** The value displayed as Mxxx is the maximum static back pressure reading. This must be entered into the CRT[®] System Service Record.



Customer Support Contacts

Website	www.eminox.com
Email	customersupport@eminox.com
Telephone	08000 850999

